## EZ Link Quick start guide

## Start up

- 1. Power device on with power button.
- 2. Unlock device by swiping padlock symbol upwards.
- 3. Log in using 3 or 4 letter Participant Code.

(If you are unsure of your code refer to the sticker on device or EZ Link box).

- 4. Select 🌣 Test Setup
- 5. Fill out mandatory fields
  - Previous cups on date.
  - Previous cups on time.
- 6. Use optional settings (if required).
  - Enable EID wand.
  - Alternate scan On/Off (herringbone only).
  - Select button to save your changes.






## **Rotary**


• Select to change bail numbers from ascending to descending.

(Can only be selected before entering first animal in session).

• Tap on the bail to bring up below options:




• Select the three dots in top right hand corner to display the following options:



NEW - When finished session select to go back to home screen and LOGOUT (there is no END SESSION button).

## Herringbone

- Select to change bail numbers from ascending to descending.
  - Alternative scan ON select before entering first animal ID in row.
  - Alternative scan OFF select before entering any animal IDs or before scanning any flasks in row.
- Select add extra Bail to add an extra bail.
- Select scan off). after entering all animal IDs. (Alternative scan off).
- Select complete row after scanning flasks to start a new row.
- Tap on the bail to bring up below options:



• Select the 3 dots in top right hand corner to the display following options:



UPDATE - Add missed flask

When a missing flask is found, users will be prompted to scan remaining flasks in the row.

This process has changed to improve accuracy of data, efficiency within the app and is now only available for herringbone sheds not using alternate scan.

- Short row skip all remaining empty bails.
  - Scroll to bottom of record screen.
  - Select SCAN FLASKS Or COMPLETE ROW
  - Confirm by selecting "Begin Scanning" or "Complete Row" on warning.

NEW - When finished session select to go back to home screen and LOGOUT (there is no END SESSION button)

If you need any further assistance call the EZ Link Support Line 0800 439 5465 (0800 4 EZLINK).

